













Pump Accessories

Single-tube Holders

Single-tube Low Flow Sampling Accessories

Build a **single-tube low flow sampling train** in three easy steps: (1) select a pump, (2) select the pump-specific tube holder, and (3) select a protective tube cover (based on sorbent tube size, see *Sorbent Tube Selection Guide on pages 48-52*). Pocket Pump TOUCH tube holders are non-adjustable and are supplied with a tube cover; select the appropriate model based on size of sorbent tube used.

Step 1	Step 2	Step 3	
Pumps AirChek 52/Sidekick AirChek XR5000 AirChek TOUCH AirChek Connect AirChek Essential AirLite AirChek 3000	Tube Holders All-in-One Low Flow/Single Adjustable Tube Holder with built-in CPC Cat. No. 224-27 See convenient Low Flow Adapter Kit below.	Tube Covers Only A (6-mm OD x 70-mm L) Cat. No. 224-29A  B (7 or 8-mm OD x 110-mm L) Cat. No. 224-29B  C (10-mm OD x 150-mm L) Cat. No. 224-29C  D (10-mm OD x 220-mm L) Cat. No. 224-29D  Select desired tube from the Sorbent Tube Selection Guide on pp. 48-52. Match the letter indicated in the Tube Cover column in the Guide to the letter above. See page 37 for specialty tube holders.	
Universal Series	Adjustable Low Flow Tube Holder Cat. No. 224-26-01		
Pocket Pump TOUCH	Low Flow Tube Holder with cover (non-adjustable) Cat. No. 222-3-1 (A) 222-3L-1 (B) 222-3XL-1 (C) 222-3XD-1 (D)		A (6-mm OD x 70-mm L)  B (7 or 8-mm OD x 110-mm L)  C (10-mm OD x 150-mm L)  D (10-mm OD x 220-mm L)  

Low Flow Adapter Kit

The SKC Low Flow Adapter Kit includes an All-in-One Low Flow Adjustable Tube Holder with built-in CPC and Type A Tube Cover. It is now even easier to adapt high flow SKC pumps for low flow applications.

Cat. No. 210-500

SKC Tube Breaker












The SKC Tube Breaker opens 6, 7, 8, and 10-mm OD glass sorbent tubes cleanly and safely. This heavy-duty breaker is constructed of sturdy stainless steel with cap that rotates to expose the desired size opener and to retain glass tips to be discarded.

Cat. No. 226-03-055



Multiple-tube Low Flow Sampling Accessories

Build a **multiple-tube low flow sampling train** in four easy steps: (1) select a pump, (2) select the constant pressure controller (if pump requires it), (3) select a tube holder, and (4) select protective tube covers (based on sorbent tube size, *see Sorbent Tube Selection Guide on pages 48-52*).

Step 1	Step 2	Step 3	Step 4	
Pumps	Constant Pressure Controller (CPC)	Adjustable Multiple-tube Low Flow Holders	Tube Covers Only	
AirChek 52/Sidekick AirChek XR5000 AirChek Connect AirChek Essential AirChek TOUCH AirChek 3000	CPC Cat. No. 224-26-CPC 	2 tubes (Dual) Cat. No. 224-26-02 	A (6-mm OD x 70-mm L) Cat. No. 224-29A 	
Pocket Pump TOUCH AirLite	CPC Cat. No. 224-26CPC-10 	3 tubes (Tri) Cat. No. 224-26-03 	B (7 or 8-mm OD x 110-mm L) Cat. No. 224-29B 	
Universal Series	None required (pump has built-in regulator)	4 tubes (Quad) Cat. No. 224-26-04 	C (10-mm OD x 150-mm L) Cat. No. 224-29C 	
			D (10-mm OD x 220-mm L) Cat. No. 224-29D 	

Select desired tube from the Sorbent Tube Selection Guide on pp. 48-52. Match the letter indicated in the Tube Cover column in the Guide to the letter above. See below for specialty tube holders.

Specialty Tube Holders

For Sorbent Tube Sampling ≥ 1 L/min Without Low Flow Accessories

OVS Tube Holder

The OVS Tube Holder accommodates the 13-mm diameter of SKC OVS Tubes.

OVS Tube Holder includes fitting with durable protective cover, 3 feet of tubing, and collar clip. *Do not use an Adjustable Low Flow Holder.*
Cat. No. 224-29V



Low-volume PUF Tube Holder

The Low-volume PUF Tube Holder accommodates the 22-mm diameter and 100-mm length of SKC Low-volume PUF Tubes.

Low-volume PUF Tube Holder includes fitting with durable protective cover, 3 feet of tubing, and collar clip. *Do not use an Adjustable Low Flow Holder.*
Cat. No. 224-29P



16-mm Diameter Tube Holder

Accommodates the 16-mm diameter of SKC Sorbent Tubes Cat. Nos. 226-142 and 226-177.

16-mm Diameter Tube Holder includes fitting with durable protective cover, 3 feet of tubing, and collar clip. *Do not use an Adjustable Low Flow Holder.*
Cat. No. 224-29H

