

SKC

Sidekick MTX Range

SKC

Tel: 01258 480188

Email: enquiries@skcltd.com

www.skcltd.com

SKC Ltd. 11 Sunrise Business Park,
Higher Shaftesbury Road,
Blandford Forum, Dorset DT11 8ST



A member of the SKC Global Group of Companies



Air Sampling Pump
for Dust, Gas and Vapours

Sidekick MTX Range

The Sidekick sampling pump - a favourite with SKC customers.

Reliability and simplicity make it a good entry level pump, whilst high build quality means it won't let you down. Available in 3 models, you have a choice of intrinsically safe versions and a standard non I/S model which offers good value for money.

Two ATEX certified models are available. All models offer a wide flow range of 5-3000 ml/min, which means the Sidekick is suitable for dust and gas sampling projects. The lower flows are achieved with the constant pressure controller and low flow adapter.

Pump Models

- 224-50MH
Standard pump with simple on/off control. Non-intrinsically safe model.
- 224-51MTX
Intermediate pump with simple on/off control. Intrinsically safe model.
- 224-52MTX
Deluxe pump with simple on/off control and elapsed time display. Intrinsically safe model.

Key Features:

- Lightweight personal sampling pumps
224-50MH - 465g
224-51MTX - 575g
224-52MTX - 575g
- Flow range:
750 to 3000 m/min (constant flow operation)
5 - 500 ml/min with adapter (constant pressure operation)
Flow control: $\pm 5\%$ of set point
- Rechargeable NiMH battery pack with a typical run time of 8 hours at 3l/min with 15 inches of water back pressure.
- Battery eliminators for running the pump continuously from mains electricity (ATEX certification is invalidated)
- The pump controls are situated beneath a clear anti-tamper cover
- Built in replaceable filter to trap particles that would otherwise contaminate the pump mechanism
- The Intermediate and Deluxe models (224-51MTX and 224-52MTX) comply with the EU ATEX Directive 2014/34/EU on equipment intended for use in potentially explosive atmospheres, as intrinsically safe to Ex ia IIC T4 Ga , for use in Europe. The standard model (224-50MH) is not ATEX certified.
- Deluxe Sidekick (224-52MTX). The pump also has a timer with LCD to indicate the run time battery status and flow fault.



Battery/Chargers

- Battery Pack
P78050MH - for standard model
P78051MTX - for intermediate and deluxe model
- 223-203A Single battery charger with multi-plugs (UK, Europe, USA and Australia)
- 223-103A Five station battery charger with multi-plugs (UK, Europe, USA and Australia)
- 223-300B Battery eliminator 230V~50Hz supply with EU 2 pin mains plug
- 223-300C Battery eliminator 230V~50Hz supply with UK 3 pin mains plug

Accessories

- 224-26-CPC Constant pressure controller
20 inches of water
- 224-26-01 Single adjustable low flow adapter/ tube holder
- chek-mate Flowmeter available in medium and low flow models:
375-0550 0.5 to 5.0 L/min
375-00205 20 to 500 ml/min



Kits also available